

FIRMINY – PAULELLO (type 0) CONVERSION TABLE

Most of French makers have used the Firminy gauge from 1885 up to about 1903. If you wish to preserve the original scaling, you will be able, thanks to the opposite table, to convert the Firminy figures indicated on the frame, the pin-block or the bridge into corresponding contemporary gauge.



Firminy	Ø (mm)	Paulello (type 0)
5	0.400	5
	0.425	5½
6	0.450	6
	0.475	6½
7	0.500	7
	0.525	8
8	0.550	8½
	0.575	9
9	0.600	9½
	0.625	10
10	0.650	10½
	0.675	11
10½	0.700	11½
11	0.725	12
11½	0.750	12½
12	0.775	13
12½	0.800	13½
13	0.825	14
13½	0.850	14½
14	0.875	15
14½	0.900	15½
15	0.925	16
15½	0.950	16½
16	0.960	/
16½	0.975	17
17	1.000	17½
17½	1.025	18
18	1.050	18½
18½	1.060	/
19	1.075	19
	1.100	19½
19½	1.125	20
20	1.150	20½
	1.175	21
20½	1.200	21½
	1.225	22
21	1.250	22½
21½	1.275	22¾
	1.300	23
22	1.320	/
22½	1.350	23½
23	1.400	24
24	1.450	24½
	1.500	25
	1.550	25½
25	1.575	
	1.600	26